

Setting up your Router for remote monitoring.

Port forwarding instructions for virtually any make and model of router can be found at www.portforward.com. Skip / close all the ads and look for your router. A link to "Port Forwarding Guides" can be found on the left.

It will present you with hundreds of programmes for which you can forward ports. Ignore these, and click on the "Default Guide" in the introductory text.

You need to set up port forwarding for the following ports, and point them all to the IP address you've assigned to your DVR (probably 192.168.1.200).

18004

9000

19090

Unless you have a static IP address (which domestic broadband services don't tend to offer by default), you'll need to set up a DYN DNS service to track your IP address as it changes. This is a service we offer for free. If you give us a call on 01573 440761 when you're in front of your computer, we'll assign you a unique URL to enter into your viewing software.